

Application Instructions

Woodoc 45 Tile and Cement Sealer

WHERE TO USE PRODUCT

For interior/exterior use. Clear, gloss or matt water-based sealer. For unglazed, porous tiles, cement, stone & brick. The product is water-repellent and stain- & oil-resistant.

HOW TO PREPARE THE SURFACE

Surface must be completely clean from dust, oil, wax, grout or other sealers. If washed, let surface dry completely (at least 8 hours). Consult with tile manufacturer for special cleaning and preparation instructions before product is used. Test on small area to ensure porosity - the product must penetrate surface immediately after application. **Do not use on old surfaces if not completely clean and oil-free.**

HOW TO APPLY THE PRODUCT

Stir well before use. Do not dilute. Use large paint brush. Apply one liberal coat; do not allow pooling. Very porous substrates may require 2nd/3rd coat. Each coat must dry completely. **Note: Allow 24 hours before using sealed surface.**

COVERAGE

5 - 12 m² per litre depending on porosity of substrate/ surface.

Gebruiksaanwysings

Woodoc 45 Teël en Sement Verseëlaar

WAAR OM PRODUK TE GEBRUIK

Vir binnenshuise/buitenshuise gebruik. Kleurlose, glans of mat waterbasisverseëlaar. Vir onverseëlde, poreuse teëls, sement, klip en steen. Die produk is waterwerend en vlek- & oliebestand.

HOE OM DIE OPPERVLAK VOOR TE BEREI

Oppervlak moet heeltemal skoon en vry wees van stof, olie, was, pleisterklei of verseëlaars. Indien gewas, laat oppervlakke heeltemal droog word (ten minste 8 ure). Indien moontlik, raadpleeg die teëlvervaardiger vir spesiale skoonmaak- en voorbereidingsinstruksies voor die produk gebruik word. Toets op klein area vir porositeit - die produk moet die oppervlak onmiddellik na aanwending binnedring. **Let Wel:** Moenie op ou oppervlakke gebruik indien hulle nie heeltemal skoon en olievry is nie.

HOE OM DIE PRODUK AAN TE WEND

Roer goed voor gebruik. Moenie verdun nie. Gebruik groot verfkwas. Wend een kwistige laag aan, maar vermy opdamming. Baie poreuse substrate mag 'n 2e/3e laag benodig. Elke laag moet heeltemal droog word. **Let Wel: Wag 24 uur voordat verseëlde oppervlak gebruik word.**

DEKKING

5 - 12 m² per liter afhangende van porositeit van substraat.