

# Application Instructions

## Totim Exterior Wood Sealer

### WHERE TO USE PRODUCT

For all exterior woodwork, where a durable weatherproof finish is required. Provides UV-protection and water repellence. Also suitable for use on roughly-sawn wood, e.g. wendy houses and fences. **Not for use on indoor woodwork.**

### HOW TO PREPARE THE SURFACE

**General:** Wood must always be clean, dry & smooth before applying Totim. Never wash/wipe wood with water before applying Totim.

**New wood:** Sand until smooth. Remove dust with clean, dry cloth. Then wipe with mineral turpentine.

**Previously varnished/sealed wood:** Remove varnish by sanding/using paint stripper. Neutralise paint stripper according to manufacturer's instructions. Allow wood to dry completely. Sand until smooth. Remove dust with clean, dry cloth. Then wipe with mineral turpentine.

**Oiled wood:** Sand until smooth. Then scrub well with steel wool and mineral turpentine. Clean off residue with clean, dry cloth. Allow surface to dry.

**Wood previously treated with Totim:** Scrub well with steel wool and mineral turpentine. Clean off residue with clean, dry cloth. Allow surface to dry.

### HOW TO APPLY THE PRODUCT

**Stir well with a flat paddle** before and during application to ensure that contents are well mixed. Do not shake or dilute Totim. Apply Totim with good quality brush. Apply first coat until surface remains evenly glossy for at least 10 minutes after application. Apply more product to dull/dry areas. Allow coat to dry **completely**. Sand lightly with steel wool. Remove dust with clean, dry cloth. Then wipe with mineral turpentine. Apply two more coats in the same way. Do not sand after third coat. **Always apply a minimum of three coats.** Treat end grain very well. Extreme weather conditions, e.g. very high/low temperatures can influence the appearance (gloss) of the final finish.

### COVERAGE

± 10 m<sup>2</sup>/litre per coat (3,3 m<sup>2</sup>/litre for 3 coats)

## Gebruiksaanwysings

### Totim Buitenshuisse Houtverseëlaar

### WAAR OM PRODUK TE GEBRUIK

Vir alle buitenshuisse houtwerk waar 'n duursame weerbestande afwerking verlang word. Verleen UV-beskerming en is waterwerend. Ook geskik vir gebruik op grofgesaagde hout, bv. tuinhuisies en heinings. **Nie vir gebruik op binnenshuisse houtwerk nie.**

### HOE OM DIE OPPERVLAK VOOR TE BEREI

**Algemeen:** Hout moet altyd skoon, droog en glad wees voor gebruik van Totim. Moet nooit hout met water was/afvee voor gebruik van Totim nie.

Nuwe hout: Skuur glad. Vee stof af met skoon, droë lap. Vee dan af met minerale terpentyn.

**Voorheen verniste/verseëide hout:** Skuur vernis af/gebruik verfstroper. Neutraliseer verfstroper volgens vervaardiger se instruksies. Laat hout heeltemal droog word. Skuur glad. Vee stof af met skoon, droë lap. Vee dan af met minerale terpentyn.

**Geoliede hout:** Skuur glad. Skrop daarna goed met staalwol en minerale terpentyn. Vee hout af met skoon, droë lap. Laat oppervlak droog word.

**Hout voorheen met Totim behandel:** Skrop goed met staalwol en minerale terpentyn. Vee hout af met skoon, droë lap. Laat oppervlak droog word.

### HOE OM DIE PRODUK AAN TE WEND

**Roer goed met 'n plat spaan** voor en gedurende aanwending om te verseker dat die inhoud goed gemeng is. Moenie Totim skud of verdun nie. Wend Totim met hoëgehalte kwas aan. Wend eerste laag aan totdat die oppervlak egalig blinknat bly vir ten minste 10 minute na aanwending. Wend nog produk op dowwe/droë kolle aan. Laat produk **heeltemal droog** word. Skuur liggies met staalwol. Vee stof af met skoon, droë lap. Vee dan af met minerale terpentyn. Wend nog 2 lae so aan. Moenie na derde laag skuur nie. **Wend altyd 'n minimum van drie lae aan.** Behandel eindgrein baie goed. Uiterste weersomstandighede, bv. baie hoë/lae temperature kan die voorkoms (glans) van die finale afwerking beïnvloed.

### DEKKING

± 10 m<sup>2</sup>/liter per laag (3,3m<sup>2</sup> per liter vir 3 lae)